

# METZ INSTALLATION INSTRUCTIONS

Surface to be adhered to should be clean, dust free, and dry.  
Concrete and brickwork should be primed before applying Metz

Can easily be cut with tin snips or a sharp knife.

Metz can be chased into concrete/brickwork in the normal way.

Metz can be dressed using a wooden or plastic mallet and roller if required.

Chases should be sealed with a proprietary mastic compatible with surface.

To install Metz please remove plastic backing sheet to expose adhesive underside.

Any overlaps should be a minimum of 75mm.

Ensure Metz is positioned accurately as removal will be almost impossible after adhesion.

Metz can be overlapped to increase the width of required flashing.

Gloves should be worn at all times to prevent accidents when using Metz.

It will form a fused bond when adhered to itself.

All normal HSE site requirements should be followed.